ASSEMBLY INSTRUCTIONS
#23: LITTLE BETSY
4’ CHILDREN’S TABLE

STEP 1: PLACE PICNIC TABLE LEGS UPRIGHT ON FLAT SURFACE, MAKING SURE THE PILOT HOLES ON THE LEGS ARE FACING INWARDS.

STEP 2: STARTING WITH THE SEATS, PLACE ONE OF THE PIPES INBETWEEN THE LEGS INSIDE OF THE GROOVES. REPEAT ON OTHER SIDE. ONCE PIPES HAVE BEEN PLACED, LAY DOWN A 2” x 10” x 4’ ON TOP OF THE LEGS, MAKING SURE TO ALIGN THE DRILLED HOLES. INSERT 3/8” x 3 ½” CARRIAGE BOLTS THROUGH THE HOLES AND SECURE IT TO THE BOTTOM OF THE LEG USING ONE 3/8” FLAT WASHER AND ONE 3/8” NUT PER BOLT. REPEAT ON OTHER SIDE.

REF#	QTY	DESCRIPTION
1	4	2” x 10” x 4’ BOARDS
2	2	TABLE LEGS
3	4	½” x 29 ½” METAL PIPES
	H23	HARDWARE KIT
4	8	3/8” SS FLAT WASHER
5	8	3/8” SS NUT
6	4	3/8” x 3 ½” CARRIAGE BOLT
7	4	3/8” x 3” CARRIAGE BOLT

STEP 3: FOR THE TABLE TOP, PLACE THE LAST 2 PIPES ON TOP OF THE LEGS INSIDE OF THE GROOVES. LAY THE TWO REMAINING BOARDS ON TOP OF THE LEGS, MAKING SURE TO ALIGN THE DRILLED HOLES. INSERT 3/8” x 3” CARRIAGE BOLTS THROUGH THE HOLES AND SECURE IT TO THE LEG USING REMAINING WASHERS AND NUTS.

STEP 4: ENSURE PICNIC TABLE IS SQUARE AND TIGHTEN ALL FASTENERS.

Your 100% recycled plastic picnic table will give you many years of pleasure and pride,

knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.



Little Betsy Assembly